


WENZHOU SHAOWU LIGHTING ELECTRICAL APPLIANCES CO., LTD.





Company Profile

The company, after years of development, has become a manufacturing, research, trade and services in one of the large modern appliances enterprises. Our products are mainly involved in electrical products, electrical construction, industrial electronics, small appliances, electrical fields, producing wall switches, sockets and other nine series of nearly one thousand kinds of products, the country has eight hundred agents, six thousand sales outlets

In the long-term practice, we advance the concept and action, take the initiative to understand and develop the market and create a brand new marketing new ideas, establish a marketing network covering the whole country, the formation of a strong brand competitiveness.

Strong technical production capacity, with a number of leading domestic technology level of production lines, a senior engineer more than twenty. Through cooperation with the domestic first-class institute, the introduction of advanced equipment, supplemented by imports of high-quality PC materials and exquisite craftsmanship, to create a life, market-leading electrical products.

Companies with strong R D strength, humane management philosophy, to provide consumers with personalized, high quality of life to enjoy. Companies strictly enforce the ISO9001:2000 international quality management system standards, and passed the national compulsory 3C certification, trying to high-quality products and high quality services to enhance the company does not group brand awareness and reputation.



Content

A1 <small>(SERIES)</small> <small>■ GOLD ■ GRAY ■ BLACK ■ WHITE</small>	01-06	SW6 <small>(SERIES)</small>	39-40
A2 <small>(SERIES)</small> <small>■ GOLD ■ GRAY ■ BLACK ■ WHITE</small>	07-12	SW7 <small>(SERIES)</small>	41-42
A3 <small>(SERIES)</small> <small>■ GOLD ■ GRAY ■ BLACK ■ PATTERN</small>	13-16	SW8 <small>(SERIES)</small>	43-44
A5 <small>(SERIES)</small> <small>■ GOLD ■ GRAY ■ BLACK ■ WHITE</small>	17-20	SW9 <small>(SERIES)</small>	45-46
A6 <small>(SERIES)</small> <small>■ GOLD ■ GRAY ■ BLACK ■ WHITE</small>	21-26	SW10 <small>(SERIES)</small>	47-50
SW1 <small>(SERIES)</small> <small>■ GOLD ■ WHITE</small>	27-28	SW11 <small>(SERIES)</small>	51-52
SW2 <small>(SERIES)</small> <small>■ WHITE</small>	29-32	SW18 <small>(SERIES)</small>	52-56
SW3 <small>(SERIES)</small> <small>■ GOLD ■ WHITE</small>	33-36	SW15 <small>(SERIES)</small>	57-58
SW5 <small>(SERIES)</small>	37-38	面板+功能件 <small>(SERIES)</small> <small>■ GOLD ■ GRAY ■ SILVER ■ WHITE</small>	59-60


SWITCH SOCKET

Provide the global home with great idea and create a beautiful home, its electrical accessories not only excellent in function, but also add unlimited fun and personalized features for your living space, we brought together singularity with inspiration, will create a unique household environment for you.

1.5°
Ultra small swing angle

2.5mm
Ultra-short key travel

6.5mm
The overall thickness




Perfect touch
technological breakthrough

Ultra Thin

Ultra Thin

The Beauty Of Thinness

2.5mm



1.5°
Ultra small swing angle

2.5mm
Ultra-short key travel

6.5mm
The overall thickness

Feel the ultra-thin
visual enjoyment

6.5mm




1.5°
Ultra small swing angle

2.5mm
Ultra-short key travel

6.5mm
The overall thickness

Ultra Thin

Installation features



Steel-plastic mixed frame
Beautiful appearance, high strength
and impact resistance, stand wear and tear.

Enhanced iron plate
1.5mm reinforced design steel frame,
surface spraying insulation process.



Integration of copper parts th effectively
reduce low temperature rising

Super nylon base
Strengthened panel

Scientific Design of Base
Flame-retardant PC base, high temperature
resistance and easy to connect.

Wire box remains
more space make wiring safely.

Safety protection door,
improve product fixation,
easy installation

The switch panel is made of
flame-retardant PC without frame design

Company provide the global home with great idea and create a beautiful home,
its electrical accessories not only excellent in function,
but also add unlimited fun and personalized features for your living space,
we brought together singularity with inspiration, will create a unique household environment for you.

A1 SERIES



Ultra Thin

1.5°

Ultra small swing angle

2.5mm

Ultra-short key travel

6.5mm

The overall thickness

In simple beauty, blooming every inch of living space, product appearance, luxurious atmosphere, combined with modern trend style design. Through high-quality products, materials and refined the production process, so the overall sense of the perfect embodiment of the switch.



Provide the global home with great idea and create a beautiful home, its electrical accessories not only excellent in function, but also add unlimited fun and personalized features for your living space, we brought together singularity with inspiration, will create a unique household environment for you.

A1 SERIES

PC Material Panel

Switch socket life Electrical



A1-01 1Gang 1 Way Switch
A1-01-1 1Gang 2 Way Switch

A1-02 1Gang 1 Way Switch
A1-02-1 1Gang 2 Way Switch

A1-03 2Gang 1 Way Switch
A1-03-1 2Gang 2 Way Switch

A1-04 3Gang 1 Way Switch
A1-04-1 3Gang 2 Way Switch

A1-05 4Gang 1 Way Switch
A1-05-1 4Gang 2 Way Switch



A1-06 Door Bell Switch

A1-07 2 Pin Socket

A1-08 MF Socket

A1-09 3 Pole Socket

A1-10 Thailand 3 Pole Socket



A1-11 Double 2 Pin Socket

A1-12 8 Pin Socket

A1-13 1Gang 1 Way Switch +Thailand Socket
A1-13-1 1Gang 2 Way Switch +Thailand Socket

A1-14 1Gang 1 Way Switch +3 Pole Socket
A1-14-1 1Gang 2 Way Switch +3 Pole Socket

A1-15 1Gang 1 Way Switch +Double 2 Pin Socket
A1-15-1 1Gang 2 Way Switch +Double 2 Pin Socket



A1-16 1Gang 1 Way Switch +MF Socket
A1-16-1 1Gang 2 Way Switch +MF Socket

A1-17 Double 3 Pole Socket

A1-18 Double 2 Pin Socket

A1-19 Double Thailand 3 Pole Socket

A1-20 2 MF Socket



A1-21 1Gang 1 Way Switch + 13A Socket



A1-22 1Gang 1 Way Switch +Double 3 Pole Socket



A1-23 Triple 3 Pole Socket



A1-24 1Gang 1 Way Switch +2 Brazil Socket



A1-25 Triple 2 Pin Socket

A1-21-1 1Gang 2 Way Switch + 13A Socket

A1-22-1 1Gang 2 Way Switch +Double 3 Pole Socket

A1-24-1 1Gang 2 Way Switch +2 Brazil Socket



A1-26 1Gang 1 Way Switch + Double 2 Pin Socket



A1-27 1Gang 1 Way Switch + 2 Italian Socket



A1-28 2 MF Socket



A1-29 2*13A Socket



A1-30 Thailand 3 Pole+USB Socket

A1-26-1 1Gang 2 Way Switch + Double 2 Pin Socket

A1-27-1 1Gang 2 Way Switch + 2 Italian Socket



A1-31 MF+USB Socket



A1-32 3 Pole+USB Socket



A1-33 3 Pole Socket+Double USB



A1-34 Double Thailand 3 Pole Socket+2USB



A1-35 Double 3 Pole Socket +2USB



A1-36 13A Socket



A1-37 1Gang 1 Way Switch and Indicator light+2 Pin Socket



A1-38 20A



A1-39 16A Germany Socket



A1-40 Double USB +16A Germany Socket

A1-37-1 1Gang 2 Way Switch and Indicator light+2 Pin Socket



A1-41 TV



A1-42 TEL Socket



A1-44 Satellite Socket



A1-45 Dimmer Switch



A1-47 Voice Control Switch

A1-43 Computer Socket

A1-46 Speed Control Switch

A1-48 Touch Switch

SWITCH SOCKET



A1-01
1Gang 1 Way Switch

A1-01-1
1Gang 2 Way Switch



A1-02
1Gang 1 Way Switch

A1-02-1
1Gang 2 Way Switch



A1-03
2Gang 1 Way Switch

A1-03-1
2Gang 2 Way Switch



A1-04
3Gang 1 Way Switch

A1-04-1
3Gang 2 Way Switch



A1-05
4Gang 1 Way Switch

A1-05-1
4Gang 2 Way Switch




A1-06
Door Bell Switch



A1-07
15A/125V



A1-08
MF Socket




A1-09
3 Pole Socket



A1-10
Thailand 3 Pole Socket



A1-11
Double 2 Pin Socket



A1-12
8 Pin Socket



A1-13
1Gang 1 Way Switch
+Thailand Socket

A1-13-1
1Gang 2 Way Switch
+Thailand Socket




A1-14
1Gang 1 Way Switch
+3 Pole Socket

A1-14-1
1Gang 2 Way Switch
+3 Pole Socket



A1-15
1Gang 1 Way Switch
+Double 2 Pin Socket

A1-15-1
1Gang 2 Way Switch
+Double 2 Pin Socket



A1-21
1Gang 1 Way Switch
+ 13A Socket

A1-21-1
1Gang 2 Way Switch
+ 13A Socket



A1-22
1Gang 1 Way Switch
+Double 3 Pole Socket

A1-22-1
1Gang 2 Way Switch
+Double 3 Pole Socket



A1-23
Triple 3 Pole Socket



A1-24
1Gang 1 Way Switch
+2 Brazil Socket

A1-24-1
1Gang 2 Way Switch
+2 Brazil Socket



A1-25
Triple 2 Pin Socket



A1-26
1Gang 1 Way Switch
+ Double 2 Pin Socket

A1-26-1
1Gang 2 Way Switch
+ Double 2 Pin Socket



A1-27
1Gang 1 Way Switch
+ 2 Italian Socket

A1-27-1
1Gang 2 Way Switch
+ 2 Italian Socket



A1-28
2 MF Socket



A1-29
2*13A Socket



A1-30
Thailand 3 Pole+USB Socket



A1-31
MF+USB Socket



A1-32
3 Pole+USB Socket




A1-33
3 Pole Socket+Double USB



A1-34
Double Thailand 3 Pole
Socket+2USB



A1-35
Double 3 Pole Socket
+2USB



A1-16
1Gang 1 Way Switch
+MF Socket

A1-16-1
1Gang 2 Way Switch
+MF Socket



A1-17
Double 3 Pole Socket




A1-18
Double 2 Pin Socket




A1-19
Double Thailand 3 Pole
Socket



A1-20
2 MF Socket



A1-41
TV



A1-42
TEL Socket

A1-43
Computer Socket



A1-44
Satellite Socket



A1-45
Dimmer Switch

A1-46
Speed Control Switch



A1-47
Voice Control Switch

A1-48
Touch Switch

Ultra Thin

1.5°

Ultra small swing angle

2.5mm

Ultra-short key travel

6.5mm

The overall thickness

A2 SERIES



WHITE



GOLD



GRAY



BLACK

Custom Color



A2 SERIES

PC Material Panel

Switch socket life Electrical



- A2-01**
1Gang 1 Way Switch
A2-01-1
1Gang 2 Way Switch
- A2-02**
1Gang 1 Way Switch
A2-02-1
1Gang 2 Way Switch
- A2-03**
2Gang 1 Way Switch
A2-03-1
2Gang 2 Way Switch
- A2-04**
3Gang 1 Way Switch
A2-04-1
3Gang 2 Way Switch
- A2-05**
4Gang 1 Way Switch
A2-05-1
4Gang 2 Way Switch



- A2-06**
Door Bell Switch
- A2-07**
2 Pin Socket
- A2-08**
MF Socket
- A2-09**
3 Pole Socket
- A2-10**
Thailand 3 Pole Socket




- A2-11**
Double 2 Pin Socket
- A2-12**
8 Pin Socket
- A2-13**
1Gang 1 Way Switch
+Thailand Socket
A2-13-1
1Gang 2 Way Switch
+Thailand Socket
- A2-14**
1Gang 1 Way Switch
+3 Pole Socket
A2-14-1
1Gang 2 Way Switch
+3 Pole Socket
- A2-15**
1Gang 1 Way Switch
+Double 2 Pin Socket
A2-15-1
1Gang 2 Way Switch
+Double 2 Pin Socket



- A2-16**
1Gang 1 Way Switch
+MF Socket
A2-16-1
1Gang 2 Way Switch
+MF Socket
- A2-17**
Double 3 Pole Socket
- A2-18**
Double 2 Pin Socket
- A2-19**
Double Thailand 3 Pole Socket
- A2-20**
2 MF Socket




- A2-21**
1Gang 1 Way Switch
+ 13A Socket
A2-21-1
1Gang 2 Way Switch
+ 13A Socket
- A2-22**
1Gang 1 Way Switch
+Double 3 Pole Socket
A2-22-1
1Gang 2 Way Switch
+Double 3 Pole Socket
- A2-23**
Triple 3 Pole Socket
- A2-24**
1Gang 1 Way Switch
+2 Brazil Socket
A2-24-1
1Gang 2 Way Switch
+2 Brazil Socket
- A2-25**
Triple 2 Pin Socket



- A2-26**
1Gang 1 Way Switch
+ Double 2 Pin Socket
A2-26-1
1Gang 2 Way Switch
+ Double 2 Pin Socket
- A2-27**
1Gang 1 Way Switch
+ 2 Italian Socket
A2-27-1
1Gang 2 Way Switch
+ 2 Italian Socket
- A2-28**
2 MF Socket
- A2-29**
2*13A Socket
- A2-30**
Thailand 3 Pole+USB Socket



- A2-31**
MF+USB Socket
- A2-32**
3 Pole+USB Socket
- A2-33**
3 Pole Socket+Double USB
- A2-34**
Double Thailand 3 Pole Socket+2USB
- A2-35**
Double 3 Pole Socket
+2USB



- A2-36**
13A Socket
- A2-37**
1Gang 1 Way Switch
and Indicator light+2 Pin Socket
A2-37-1
1Gang 2 Way Switch
and Indicator light+2 Pin Socket
- A2-38**
20A
- A2-39**
16A Germany Socket
- A2-40**
Double USB
+16A Germany Socket



- A2-41**
TV
- A2-42**
TEL Socket
A2-43
Computer Socket
- A2-44**
Satellite Socket
- A2-45**
Dimmer Switch
A2-46
Speed Control Switch
- A2-47**
Voice Control Switch
A2-48
Touch Switch

SWITCH SOCKET



A2-01
1Gang 1 Way Switch

A2-01-1
1Gang 2 Way Switch



A2-02
1Gang 1 Way Switch

A2-02-1
1Gang 2 Way Switch



A2-03
2Gang 1 Way Switch

A2-03-1
2Gang 2 Way Switch



A2-04
3Gang 1 Way Switch

A2-04-1
3Gang 2 Way Switch



A2-05
4Gang 1 Way Switch

A2-05-1
4Gang 2 Way Switch



A2-06
Door Bell Switch



A2-07
15A/125V



A2-08
MF Socket



A2-09
3 Pole Socket



A2-10
Thailand 3 Pole Socket



A2-11
Double 2 Pin Socket



A2-12
8 Pin Socket



A2-13
1Gang 1 Way Switch
+Thailand Socket

A2-13-1
1Gang 2 Way Switch
+Thailand Socket




A2-14
1Gang 1 Way Switch
+3 Pole Socket

A2-14-1
1Gang 2 Way Switch
+3 Pole Socket



A2-15
1Gang 1 Way Switch
+Double 2 Pin Socket

A2-15-1
1Gang 2 Way Switch
+Double 2 Pin Socket



A2-21
1Gang 1 Way Switch
+ 13A Socket

A2-21-1
1Gang 2 Way Switch
+ 13A Socket



A2-22
1Gang 1 Way Switch
+Double 3 Pole Socket

A2-22-1
1Gang 2 Way Switch
+Double 3 Pole Socket



A2-23
Triple 3 Pole Socket



A2-24
1Gang 1 Way Switch
+2 Brazil Socket

A2-24-1
1Gang 2 Way Switch
+2 Brazil Socket



A2-25
Triple 2 Pin Socket




A2-26
1Gang 1 Way Switch
+ Double 2 Pin Socket

A2-26-1
1Gang 2 Way Switch
+ Double 2 Pin Socket



A2-27
1Gang 1 Way Switch
+ 2 Italian Socket


A2-27-1
1Gang 2 Way Switch
+ 2 Italian Socket



A2-28
2 MF Socket



A2-29
2*13A Socket



A2-30
Thailand 3 Pole+USB Socket



A2-31
MF+USB Socket



A2-32
3 Pole+USB Socket



A2-33
3 Pole Socket+Double USB



A2-34
Double Thailand 3 Pole
Socket+2USB



A2-35
Double 3 Pole Socket
+2USB




A2-36
13A Socket




A2-37
1Gang 1 Way Switch
and Indicator light+2 Pin Socket

A2-37-1
1Gang 2 Way Switch
and Indicator light+2 Pin Socket



A2-38
20A



A2-39
16A Germany Socket



A2-40
Double USB
+16A Germany Socket



A2-16
1Gang 1 Way Switch
+MF Socket

A2-16-1
1Gang 2 Way Switch
+MF Socket




A2-17
Double 3 Pole Socket




A2-18
Double 2 Pin Socket




A2-19
Double Thailand 3 Pole
Socket



A2-20
2 MF Socket




A2-41
TV



A2-42
TEL Socket

A2-43
Computer Socket



A2-44
Satellite Socket



A2-45
Dimmer Switch


A2-46
Speed Control Switch



A2-47
Voice Control Switch

A2-48
Touch Switch

Acrylic Art



Ultra Thin

1.5°

Ultra small swing angle

2.5mm


Ultra-short key travel

6.5mm

The overall thickness

A3 SERIES

Acrylic Crystal Panel



GOLD



GRAY



BLACK




PATTERN

A3 SERIES

Acrylic Crystal Panel

Switch socket life Electrical



GOLD



GRAY



BLACK



PATTERN



A3-01
1Gang 1 Way Switch

A3-01-1
1Gang 2 Way Switch



A3-02
1Gang 1 Way Switch

A3-02-1
1Gang 2 Way Switch



A3-03
2Gang 1 Way Switch

A3-03-1
2Gang 2 Way Switch




A3-04
3Gang 1 Way Switch

A3-04-1
3Gang 2 Way Switch



A3-05
4Gang 1 Way Switch

A3-05-1
4Gang 2 Way Switch



A3-06
Door Bell Switch



A3-07
2 Pin Socket



A3-08
MF Socket



A3-09
3 Pole Socket



A3-10
Thailand 3 Pole Socket



A3-11
Double 2 Pin Socket



A3-12
8 Pin Socket



A3-13
1Gang 1 Way Switch
+Thailand Socket

A3-13-1
1Gang 2 Way Switch
+Thailand Socket




A3-14
1Gang 1 Way Switch
+3 Pole Socket

A3-14-1
1Gang 2 Way Switch
+3 Pole Socket



A3-15
1Gang 1 Way Switch
+Double 2 Pin Socket

A3-15-1
1Gang 2 Way Switch
+Double 2 Pin Socket



A3-16
1Gang 1 Way Switch
+MF Socket

A3-16-1
1Gang 2 Way Switch
+MF Socket



A3-17
Double 3 Pole Socket




A3-18
Double 2 Pin Socket



A3-19
Double Thailand 3 Pole Socket



A3-20
2 MF Socket



A3-21
1Gang 1 Way Switch
+ 13A Socket

A3-21-1
1Gang 2 Way Switch
+ 13A Socket



A3-22
1Gang 1 Way Switch
+Double 3 Pole Socket

A3-22-1
1Gang 2 Way Switch
+Double 3 Pole Socket



A3-23
Triple 3 Pole Socket



A3-24
1Gang 1 Way Switch
+2 Brazil Socket

A3-24-1
1Gang 2 Way Switch
+2 Brazil Socket



A3-25
Triple 2 Pin Socket




A3-26
1Gang 1 Way Switch
+ Double 2 Pin Socket

A3-26-1
1Gang 2 Way Switch
+ Double 2 Pin Socket




A3-27
1Gang 1 Way Switch
+ 2 Italian Socket

A3-27-1
1Gang 2 Way Switch
+ 2 Italian Socket



A3-28
2 MF Socket



A3-29
2*13A Socket



A3-30
Thailand 3 Pole+USB Socket



A3-31
MF+USB Socket



A3-32
3 Pole+USB Socket



A3-33
3 Pole Socket+Double USB



A3-34
Double Thailand 3 Pole Socket+2USB



A3-35
Double 3 Pole Socket
+2USB



A3-36
13A Socket



A3-37
1Gang 1 Way Switch
and Indicator light+2 Pin Socket

A3-37-1
1Gang 2 Way Switch
and Indicator light+2 Pin Socket




A3-38
20A



A3-39
16A Germany Socket



A3-40
Double USB
+16A Germany Socket



A3-41
TV



A3-42
TEL Socket

A3-43
Computer Socket



A3-44
Satelite Socket



A3-45
Dimmer Switch

A3-46
Speed Control Switch



A3-47
Voice Control Switch

A3-48
Touch Switch

A5 SERIES
Ultra Thin Plan
SWITCH & SOCKET



Provide the global home with great idea and create a beautiful home,
its electrical accessories not only excellent in function,
but also add unlimited fun and personalized features for your living space,
we brought together singularity with inspiration, will create a unique household environment for you.

1.5°

Ultra small swing angle

2.5mm

Ultra-short key travel

6.5mm

The overall thickness




Custom Color:

WHITE SILVER GOLD GRAY Black

A5 SERIES

PC Material Panel

□ Switch socket Ⓢ life Electrical



- A5-01**
1Gang 1 Way Switch
A5-01-1
1Gang 2 Way Switch
- A5-02**
1Gang 1 Way Switch
A5-02-1
1Gang 2 Way Switch
- A5-03**
2Gang 1 Way Switch
A5-03-1
2Gang 2 Way Switch
- A5-04**
3Gang 1 Way Switch
A5-04-1
3Gang 2 Way Switch
- A5-05**
4Gang 1 Way Switch
A5-05-1
4Gang 2 Way Switch




- A5-06**
Door Bell Switch
- A5-07**
2 Pin Socket
- A5-08**
MF Socket
- A5-09**
3 Pole Socket
- A5-10**
Thailand 3 Pole Socket




- A5-11**
Double 2 Pin Socket
- A5-12**
8 Pin Socket
- A5-13**
1Gang 1 Way Switch
+Thailand Socket
A5-13-1
1Gang 2 Way Switch
+Thailand Socket
- A5-14**
1Gang 1 Way Switch
+3 Pole Socket
A5-14-1
1Gang 2 Way Switch
+3 Pole Socket
- A5-15**
1Gang 1 Way Switch
+Double 2 Pin Socket
A5-15-1
1Gang 2 Way Switch
+Double 2 Pin Socket



- A5-16**
1Gang 1 Way Switch
+MF Socket
A5-16-1
1Gang 2 Way Switch
+MF Socket
- A5-17**
Double 3 Pole Socket
- A5-18**
Double 2 Pin Socket
- A5-19**
Double Thailand 3 Pole Socket
- A5-20**
2 MF Socket




- A5-21**
1Gang 1 Way Switch
+ 13A Socket
A5-21-1
1Gang 2 Way Switch
+ 13A Socket
- A5-22**
1Gang 1 Way Switch
+Double 3 Pole Socket
A5-22-1
1Gang 2 Way Switch
+Double 3 Pole Socket
- A5-23**
Triple 3 Pole Socket
- A5-24**
1Gang 1 Way Switch
+2 Brazil Socket
A5-24-1
1Gang 2 Way Switch
+2 Brazil Socket
- A5-25**
Triple 2 Pin Socket



- A5-26**
1Gang 1 Way Switch
+ Double 2 Pin Socket
A5-26-1
1Gang 2 Way Switch
+ Double 2 Pin Socket
- A5-27**
1Gang 1 Way Switch
+ 2 Italian Socket
A5-27-1
1Gang 2 Way Switch
+ 2 Italian Socket
- A5-28**
2 MF Socket
- A5-29**
2*13A Socket
- A5-30**
Thailand 3 Pole+USB Socket



- A5-31**
MF+USB Socket
- A5-32**
3 Pole+USB Socket
- A5-33**
3 Pole Socket+Double USB
- A5-34**
Double Thailand 3 Pole Socket+2USB
- A5-35**
Double 3 Pole Socket
+2USB



- A5-36**
13A Socket
- A5-37**
1Gang 1 Way Switch
and Indicator light+2 Pin Socket
A5-37-1
1Gang 2 Way Switch
and Indicator light+2 Pin Socket
- A5-38**
20A
- A5-39**
16A Germany Socket
- A5-40**
Double USB
+16A Germany Socket



- A5-41**
TV
- A5-42**
TEL Socket
A5-43
Computer Socket
- A5-44**
Satelite Socket
- A5-45**
Dimmer Switch
A5-46
Speed Control Switch
- A5-47**
Voice Control Switch
A5-48
Touch Switch

A6 SERIES
PC Material Panel



provide the global home with great idea and create a beautiful home,
its electrical accessories not only excellent in function,
but also add unlimited fun and personalized features for your living space,
we brought together singularity with inspiration, will create a unique household environment for you.

Modern / *Beyond*



Custom Color:

- WHITE+SILVER
- WHITE+GOLD
- GOLD
- GRAY
- BLACK

A6 SERIES

PC Material Panel

Switch socket life Electrical



A6-01
1Gang 1 Way Switch
A6-01-1
1Gang 2 Way Switch



A6-02
1Gang 1 Way Switch
A6-02-1
1Gang 2 Way Switch



A6-03
2Gang 1 Way Switch
A6-03-1
2Gang 2 Way Switch



A6-04
3Gang 1 Way Switch
A6-04-1
3Gang 2 Way Switch



A6-05
4Gang 1 Way Switch
A6-05-1
4Gang 2 Way Switch



A6-06
Door Bell Switch



A6-07
2 Pin Socket



A6-08
MF Socket



A6-09
3 Pole Socket



A6-10
Thailand 3 Pole Socket



A6-11
Double 2 Pin Socket



A6-12
8 Pin Socket



A6-13
1Gang 1 Way Switch
+Thailand Socket
A6-13-1
1Gang 2 Way Switch
+Thailand Socket



A6-14
1Gang 1 Way Switch
+3 Pole Socket
A6-14-1
1Gang 2 Way Switch
+3 Pole Socket



A6-15
1Gang 1 Way Switch
+Double 2 Pin Socket
A6-15-1
1Gang 2 Way Switch
+Double 2 Pin Socket



A6-16
1Gang 1 Way Switch
+MF Socket
A6-16-1
1Gang 2 Way Switch
+MF Socket



A6-17
Double 3 Pole Socket



A6-18
Double 2 Pin Socket




A6-19
Double Thailand 3 Pole Socket



A6-20
2 MF Socket




A6-21
1Gang 1 Way Switch
+ 13A Socket



A6-21-1
1Gang 2 Way Switch
+ 13A Socket



A6-22
1Gang 1 Way Switch
+Double 3 Pole Socket




A6-22-1
1Gang 2 Way Switch
+Double 3 Pole Socket



A6-23
Triple 3 Pole Socket



A6-24
1Gang 1 Way Switch
+2 Brazil Socket



A6-24-1
1Gang 2 Way Switch
+2 Brazil Socket




A6-25
Triple 2 Pin Socket



A6-26
1Gang 1 Way Switch
+ Double 2 Pin Socket
A6-26-1
1Gang 2 Way Switch
+ Double 2 Pin Socket



A6-27
1Gang 1 Way Switch
+ 2 Italian Socket
A6-27-1
1Gang 2 Way Switch
+ 2 Italian Socket



A6-28
2 MF Socket



A6-29
2*13A Socket



A6-30
Thailand 3 Pole+USB Socket



A6-31
MF+USB Socket




A6-32
3 Pole+USB Socket



A6-33
3 Pole Socket+Double USB



A6-34
Double Thailand 3 Pole Socket+2USB



A6-35
Double 3 Pole Socket
+2USB



A6-36
13A Socket



A6-37
1Gang 1 Way Switch
and Indicator light+2 Pin Socket
A6-37-1
1Gang 2 Way Switch
and Indicator light+2 Pin Socket



A6-38
20A



A6-39
16A Germany Socket



A6-40
Double USB
+16A Germany Socket



A6-41
TV



A6-42
TEL Socket



A6-44
Satellite Socket



A6-45
Dimmer Switch



















































A6-46
Speed Control Switch



A6-47
Voice Control Switch

A6-48
Touch Switch

SWITCH SOCKET

									
A6-01 1Gang 1 Way Switch A6-01-1 1Gang 2 Way Switch	A6-02 1Gang 1 Way Switch A6-02-1 1Gang 2 Way Switch	A6-03 2Gang 1 Way Switch A6-03-1 2Gang 2 Way Switch	A6-04 3Gang 1 Way Switch A6-04-1 3Gang 2 Way Switch	A6-05 4Gang 1 Way Switch A6-05-1 4Gang 2 Way Switch	A6-21 1Gang 1 Way Switch + 13A Socket A6-21-1 1Gang 2 Way Switch + 13A Socket	A6-22 1Gang 1 Way Switch +Double 3 Pole Socket A6-22-1 1Gang 2 Way Switch +Double 3 Pole Socket	A6-23 Triple 3 Pole Socket	A6-24 1Gang 1 Way Switch +2 Brazil Socket A6-24-1 1Gang 2 Way Switch +2 Brazil Socket	A6-25 Triple 2 Pin Socket
									
A6-06 Door Bell Switch	A6-07 15A/125V	A6-08 MF Socket	A6-09 3 Pole Socket	A6-10 Thailand 3 Pole Socket	A6-26 1Gang 1 Way Switch + Double 2 Pin Socket A6-26-1 1Gang 2 Way Switch + Double 2 Pin Socket	A6-27 1Gang 1 Way Switch + 2 Italian Socket A6-27-1 1Gang 2 Way Switch + 2 Italian Socket	A6-28 2 MF Socket	A6-29 2*13A Socket	A6-30 Thailand 3 Pole+USB Socket
									
A6-11 Double 2 Pin Socket	A6-12 8 Pin Socket	A6-13 1Gang 1 Way Switch +Thailand Socket A6-13-1 1Gang 2 Way Switch +Thailand Socket	A6-14 1Gang 1 Way Switch +3 Pole Socket A6-14-1 1Gang 2 Way Switch +3 Pole Socket	A6-15 1Gang 1 Way Switch +Double 2 Pin Socket A6-15-1 1Gang 2 Way Switch +Double 2 Pin Socket	A6-31 MF+USB Socket	A6-32 3 Pole+USB Socket	A6-33 3 Pole Socket+Double USB	A6-34 Double Thailand 3 Pole Socket+2USB	A6-35 Double 3 Pole Socket +2USB
									
A6-16 1Gang 1 Way Switch +MF Socket A6-16-1 1Gang 2 Way Switch +MF Socket	A6-17 Double 3 Pole Socket	A6-18 Double 2 Pin Socket	A6-19 Double Thailand 3 Pole Socket	A6-20 2 MF Socket	A6-36 13A Socket	A6-37 1Gang 1 Way Switch and Indicator light+2 Pin Socket A6-37-1 1Gang 2 Way Switch and Indicator light+2 Pin Socket	A6-38 20A	A6-39 16A Germany Socket	A6-40 Double USB +16A Germany Socket
									
A6-41 TV	A6-42 TEL Socket A6-43 Computer Socket	A6-44 Satellite Socket	A6-45 Dimmer Switch A6-46 Speed Control Switch	A6-47 Voice Control Switch A6-48 Touch Switch					




SW1-11
1Gang 1 Way Switch
+Thailand Socket



SW1-12
1Gang 1 Way Switch
+3 Pole Socket



SW1-13
1Gang 1 Way Switch
+MF Socket



SW1-14
2 MF Socket



SW1-15
2*13A Socket

SW1-11-1
1Gang 2 Way Switch
+Thailand Socket

SW1-12-1
1Gang 2 Way Switch
+3 Pole Socket

SW1-13-1
1Gang 2 Way Switch
+MF Socket



SW1-16
Double 2 Pin Socket



SW1-17
Double 3 Pole Socket



SW1-18
Double Thailand
3 Pole Socket



SW1-19
1Gang 1 Way Switch
+Double 2 Pin Socket



SW1-20
1Gang 1 Way Switch
+Double 3 Pole Socket



SW1-21
1Gang 1 Way Switch
+2 Brazil Socket



SW1-22
Triple 2 Pin Socket



SW1-23
Triple 3 Pole Socket



SW1-24
6 Pole Socket
+ USB



SW1-25
16A Germany Socket

SW1-21-1
1Gang 2 Way Switch
+2 Brazil Socket

SW1-19-1
1Gang 2 Way Switch
+Double 2 Pin Socket

SW1-20-1
1Gang 2 Way Switch
+Double 3 Pole Socket



SW1-01
1Gang 1 Way Switch



SW1-02
1Gang 1 Way Switch



SW1-03
2Gang 1 Way Switch



SW1-04
3Gang 1 Way Switch



SW1-05
4Gang 1 Way Switch

SW1-01-1
1Gang 2 Way Switch

SW1-02-1
1Gang 2 Way Switch

SW1-03-1
2Gang 2 Way Switch

SW1-04-1
3Gang 2 Way Switch

SW1-05-1
4Gang 2 Way Switch



SW1-26
1Gang 1 Way Switch
+16A Germany Socket



SW1-27
Thailand 3 Pole+USB Socket



SW1-28
3 Pole+USB Socket



SW1-29
1Gang 1 Way Switch
and Indicator light+2 Pin Socket



SW1-30
20-25A

SW1-26-1
1Gang 2 Way Switch
+16A Germany Socket

SW1-29-1
1Gang 2 Way Switch
and Indicator light+2 Pin Socket



SW1-06
Door Bell Switch



SW1-07
2 Pin Socket



SW1-08
3 Pole Socket



SW1-09
Thailand 3 Pole Socket



SW1-10
2 MF Socket



SW1-31
TV



SW1-32
TEL Socket



SW1-34
Satellite Socket



SW1-35
Dimmer Switch



SW1-37
Voice Control Switch

SW1-33
Computer Socket

SW1-36
Speed Control Switch

SW1-38
Touch Switch



SW2 SERIES

Provide the global home with great idea and create a beautiful home,
its electrical accessories not only excellent in function,
but also add unlimited fun and personalized features for your living space,
we brought together singularity with inspiration, will create a unique household environment for you.



SW2 SERIES
PC Material Panel


**SWITCH
SOCKET**



SW2-22
1Gang 1 Way Switch
SW2-22-1
1Gang 2 Way Switch



SW2-23
1Gang 1 Way Switch
SW2-23-1
1Gang 2 Way Switch



SW2-24
2Gang 1 Way Switch
SW2-24-1
2Gang 2 Way Switch



SW2-25
3Gang 1 Way Switch
SW2-25-1
3Gang 2 Way Switch



SW2-26
4Gang 1 Way Switch
SW2-26-1
4Gang 2 Way Switch




SW2-01
1Gang 1 Way Switch
SW2-01-1
1Gang 2 Way Switch




SW2-02
2Gang 1 Way Switch
SW2-02-1
2Gang 2 Way Switch



SW2-03
1Gang 1 Way Switch
+ 2 Pin Socket
SW2-03-1
1Gang 2 Way Switch
+ 2 Pin Socket



SW2-04
1Gang 1 Way Switch
+3 Pole Socket
SW2-04-1
1Gang 2 Way Switch
+3 Pole Socket



SW2-05
1Gang 1 Way Switch
+ Italian Socket
SW2-05-1
1Gang 2 Way Switch
+ Italian Socket



SW2-27
Door Bell Switch



SW2-28
2 Pin Socket



SW2-29
3 Pole Socket



SW2-30
Thailand 3 Pole Socket



SW2-31
MF Socket



SW2-06
Double 2 Pin Socket




SW2-07
1Gang 1 Way Switch
+Double 3 Pole Socket
SW2-07-1
1Gang 2 Way Switch
+Double 3 Pole Socket



SW2-08
1Gang 1 Way Switch
+2 Brazil Socket
SW2-08-1
1Gang 2 Way Switch
+2 Brazil Socket



SW2-09
Triple 2 Pin Socket



SW2-10
Triple 3 Pole Socket



SW2-32
2 MF Socket




SW2-33
1Gang 1 Way Switch
+Thailand Socket
SW2-33-1
1Gang 2 Way Switch
+Thailand Socket



SW2-34
1Gang 1 Way Switch
+3 Pole Socket
SW2-34-1
1Gang 2 Way Switch
+3 Pole Socket




SW2-35
1Gang 1 Way Switch
+MF Socket
SW2-35-1
1Gang 2 Way Switch
+MF Socket



SW2-36
Double 2 Pin Socket




SW2-11
6 Pole Socket
+ USB



SW2-12
16A Germany Socket



SW2-13
1Gang 1 Way Switch
+ 16A Germany Socket
SW2-13-1
1Gang 2 Way Switch
+ 16A Germany Socket




SW2-14
2 MF Socket



SW2-15
2*13A Socket



SW2-37
Double 3 Pole Socket



SW2-38
Double Thailand
3 Pole Socket



SW2-39
Thailand 3 Pole+USB Socket



SW2-40
MF+USB Socket



SW2-41
3 Pole+USB Socket



SW2-16
TV



SW2-17
TEL Socket



SW2-19
Satellite Socket



SW2-20
1Gang 1 Way Switch
and Indicator light+2 Pin Socket
SW2-20-1
1Gang 2 Way Switch
and Indicator light+2 Pin Socket



SW2-21
20-25A



SW2-42
TV



SW2-43
TEL Socket



SW2-45
Satellite Socket



SW2-46
Dimmer Switch



SW2-48
Voice Control Switch

SW2-18
Computer Socket

SW2-44
Computer Socket


SW2-47
Speed Control Switch

SW2-49
Touch Switch

PC Material Panel

SW3^{GOLD}

art switch
Fashion



SW3-01
1Gang 1 Way Switch
SW3-01-1
1Gang 2 Way Switch

SW3-02
1Gang 1 Way Switch
SW3-02-1
1Gang 2 Way Switch

SW3-03
2Gang 1 Way Switch
SW3-03-1
2Gang 2 Way Switch

SW3-04
3Gang 1 Way Switch
SW3-04-1
3Gang 2 Way Switch

SW3-05
4Gang 1 Way Switch
SW3-05-1
4Gang 2 Way Switch


SW3-06
Door Bell Switch

SW3-07
2 Pin Socket

SW3-08
3 Pole Socket

SW3-09
Thailand 3 Pole Socket

SW3-10
2 MF Socket



SW3-11
1Gang 1 Way Switch
+Thailand Socket

SW3-12
1Gang 1 Way Switch
+3 Pole Socket

SW3-13
1Gang 1 Way Switch
+MF Socket

SW3-14
2 MF Socket

SW3-15
2*13A Socket

SW3-11-1
1Gang 2 Way Switch
+Thailand Socket

SW3-12-1
1Gang 2 Way Switch
+3 Pole Socket

SW3-13-1
1Gang 2 Way Switch
+MF Socket

SW3-16
Double 2 Pin Socket

SW3-17
Double 3 Pole Socket

SW3-18
Double Thailand
3 Pole Socket

SW3-19
1Gang 1 Way Switch
+Double 2 Pin Socket

SW3-19-1
1Gang 2 Way Switch
+Double 2 Pin Socket

SW3-20
1Gang 1 Way Switch
+Double 3 Pole Socket

SW3-20-1
1Gang 2 Way Switch
+Double 3 Pole Socket

SW3-21
1Gang 1 Way Switch
+2 Brazil Socket

SW3-22
Triple 2 Pin Socket

SW3-23
Triple 3 Pole Socket

SW3-24
6 Pole Socket + USB

SW3-25
16A Germany Socket

SW3-21-1
1Gang 2 Way Switch
+2 Brazil Socket

SW3-26
1Gang 1 Way Switch
+ 16A Germany Socket

SW3-26-1
1Gang 2 Way Switch
+ 16A Germany Socket

SW3-27
Thailand 3 Pole+USB Socket

SW3-28
3 Pole+USB Socket

SW3-29
1Gang 1 Way Switch
and Indicator light+2 Pin Socket

SW3-29-1
1Gang 2 Way Switch
and Indicator light+2 Pin Socket

SW3-30
20-25A

SW3-31
TV

SW3-32
TEL Socket

SW3-33
Computer Socket

SW3-34
Satelite Socket

SW3-35
Dimmer Switch

SW3-36
Speed Control Switch

SW3-37
Voice Control Switch

SW3-38
Touch Switch



SW3-11
1Gang 1 Way Switch
+Thailand Socket



SW3-12
1Gang 1 Way Switch
+3 Pole Socket



SW3-13
1Gang 1 Way Switch
+MF Socket



SW3-14
2 MF Socket



SW3-15
2*13A Socket

SW3-11-1
1Gang 2 Way Switch
+Thailand Socket

SW3-12-1
1Gang 2 Way Switch
+3 Pole Socket

SW3-13-1
1Gang 2 Way Switch
+MF Socket



SW3-16
Double 2 Pin Socket




SW3-17
Double 3 Pole Socket



SW3-18
Double Thailand
3 Pole Socket



SW3-19
1Gang 1 Way Switch
+Double 2 Pin Socket




SW3-20
1Gang 1 Way Switch
+Double 3 Pole Socket



SW3-21
1Gang 1 Way Switch
+2 Brazil Socket



SW3-22
Triple 2 Pin Socket



SW3-23
Triple 3 Pole Socket



SW3-24
6 Pole Socket
+ USB



SW3-25
16A Germany Socket

SW3-21-1
1Gang 2 Way Switch
+2 Brazil Socket

SW3-19-1
1Gang 2 Way Switch
+Double 2 Pin Socket

SW3-20-1
1Gang 2 Way Switch
+Double 3 Pole Socket



SW3-01
1Gang 1 Way Switch



SW3-02
1Gang 1 Way Switch



SW3-03
2Gang 1 Way Switch



SW3-04
3Gang 1 Way Switch



SW3-05
4Gang 1 Way Switch

SW3-01-1
1Gang 2 Way Switch

SW3-02-1
1Gang 2 Way Switch

SW3-03-1
2Gang 2 Way Switch

SW3-04-1
3Gang 2 Way Switch

SW3-05-1
4Gang 2 Way Switch



SW3-26
1Gang 1 Way Switch
+ 16A Germany Socket



SW3-27
Thailand 3 Pole+USB Socket



SW3-28
3 Pole+USB Socket



SW3-29
1Gang 1 Way Switch
and Indicator light+2 Pin Socket



SW3-30
20-25A

SW3-26-1
1Gang 2 Way Switch
+ 16A Germany Socket

SW3-29-1
1Gang 2 Way Switch
and Indicator light+2 Pin Socket



SW3-06
Door Bell Switch



SW3-07
15A/125V




SW3-08
3 Pole Socket



SW3-09
Thailand 3 Pole Socket



SW3-10
2 MF Socket



SW3-31
TV



SW3-32
TEL Socket



SW3-34
Satellite Socket



SW3-35
Dimmer Switch



SW3-37
Voice Control Switch

SW3-33
Computer Socket

SW3-36
Speed Control Switch


SW3-38
Touch Switch




art switch
Fashion

SW5 SERIES

provide the global home with great idea and create a beautiful home, its electrical accessories not only excellent in function, but also add unlimited fun and personalized features for your living space, we brought together singularity with inspiration, will create a unique household environment for you.



SW5-01 1Gang 1 Way Switch SW5-01-1 1Gang 2 Way Switch	SW5-02 1Gang 1 Way Switch SW5-02-1 1Gang 2 Way Switch	SW5-03 2Gang 1 Way Switch SW5-03-1 2Gang 2 Way Switch	SW5-04 3Gang 1 Way Switch SW5-04-1 3Gang 2 Way Switch	SW5-05 4Gang 1 Way Switch SW5-05-1 4Gang 2 Way Switch
SW5-06 Door Bell Switch	SW5-07 2 Pin Socket	SW5-08 3 Pole Socket	SW5-09 Thailand 3 Pole Socket	SW5-10 2 MF Socket



SW5-11 1Gang 1 Way Switch +Thailand Socket SW5-11-1 1Gang 2 Way Switch +Thailand Socket	SW5-12 1Gang 1 Way Switch +3 Pole Socket SW5-12-1 1Gang 2 Way Switch +3 Pole Socket	SW5-13 1Gang 1 Way Switch +MF Socket SW5-13-1 1Gang 2 Way Switch +MF Socket	SW5-14 2 MF Socket	SW5-15 2*13A Socket
SW5-16 Double 2 Pin Socket	SW5-17 Double 3 Pole Socket	SW5-18 Double Thailand 3 Pole Socket	SW5-19 1Gang 1 Way Switch +Double 2 Pin Socket SW5-19-1 1Gang 2 Way Switch +Double 2 Pin Socket	SW5-20 1Gang 1 Way Switch +Double 3 Pole Socket SW5-20-1 1Gang 2 Way Switch +Double 3 Pole Socket
SW5-21 1Gang 1 Way Switch +2 Brazil Socket SW5-21-1 1Gang 2 Way Switch +2 Brazil Socket	SW5-22 Triple 2 Pin Socket	SW5-23 Triple 3 Pole Socket	SW5-24 6 Pole Socket + USB	SW5-25 16A Germany Socket
SW5-26 1Gang 1 Way Switch + 16A Germany Socket SW5-26-1 1Gang 2 Way Switch + 16A Germany Socket	SW5-27 Thailand 3 Pole+USB Socket	SW5-28 3 Pole+USB Socket	SW5-29 1Gang 1 Way Switch and Indicator light+2 Pin Socket SW5-29-1 1Gang 2 Way Switch and Indicator light+2 Pin Socket	SW5-30 20-25A
SW5-31 TV	SW5-32 TEL Socket SW5-33 Computer Socket	SW5-34 Satellite Socket	SW5-35 Dimmer Switch SW5-36 Speed Control Switch	SW5-37 Voice Control Switch SW5-38 Touch Switch



SW6 SERIES

Plastic brushed panel.



SW6-01 1Gang 1 Way Switch	SW6-02 1Gang 1 Way Switch	SW6-03 2Gang 1 Way Switch	SW6-04 3Gang 1 Way Switch	SW6-05 4Gang 1 Way Switch
SW6-01-1 1Gang 2 Way Switch	SW6-02-1 1Gang 2 Way Switch	SW6-03-1 2Gang 2 Way Switch	SW6-04-1 3Gang 2 Way Switch	SW6-05-1 4Gang 2 Way Switch
SW6-06 Door Bell Switch	SW6-07 2 Pin Socket	SW6-08 3 Pole Socket	SW6-09 Thailand 3 Pole Socket	SW6-10 2 MF Socket



SW6-11 1Gang 1 Way Switch +Thailand Socket	SW6-12 1Gang 1 Way Switch +3 Pole Socket	SW6-13 1Gang 1 Way Switch +MF Socket	SW6-14 2 MF Socket	SW6-15 2*13A Socket
SW6-11-1 1Gang 2 Way Switch +Thailand Socket	SW6-12-1 1Gang 2 Way Switch +3 Pole Socket	SW6-13-1 1Gang 2 Way Switch +MF Socket		
SW6-16 Double 2 Pin Socket	SW6-17 Double 3 Pole Socket	SW6-18 Double Thailand 3 Pole Socket	SW6-19 1Gang 1 Way Switch +Double 2 Pin Socket	SW6-20 1Gang 1 Way Switch +Double 3 Pole Socket
			SW6-19-1 1Gang 2 Way Switch +Double 2 Pin Socket	SW6-20-1 1Gang 2 Way Switch +Double 3 Pole Socket
SW6-21 1Gang 1 Way Switch +2 Brazil Socket	SW6-22 Triple 2 Pin Socket	SW6-23 Triple 3 Pole Socket	SW6-24 6 Pole Socket + USB	SW6-25 16A Germany Socket
SW6-21-1 1Gang 2 Way Switch +2 Brazil Socket				











SW6-26 1Gang 1 Way Switch + 16A Germany Socket	SW6-27 Thailand 3 Pole+USB Socket	SW6-28 3 Pole+USB Socket	SW6-29 1Gang 1 Way Switch and Indicator light+2 Pin Socket	SW6-30 20-25A
SW6-26-1 1Gang 2 Way Switch + 16A Germany Socket			SW6-29-1 1Gang 2 Way Switch and Indicator light+2 Pin Socket	
SW6-31 TV	SW6-32 TEL Socket	SW6-34 Satellite Socket	SW6-35 Dimmer Switch	SW6-37 Voice Control Switch
	SW6-33 Computer Socket		SW6-36 Speed Control Switch	SW6-38 Touch Switch


























SW7 SERIES

PC Material Panel



art switch
Fashion

				
SW7-01 1Gang 1 Way Switch SW7-01-1 1Gang 2 Way Switch	SW7-02 1Gang 1 Way Switch SW7-02-1 1Gang 2 Way Switch	SW7-03 2Gang 1 Way Switch SW7-03-1 2Gang 2 Way Switch	SW7-04 3Gang 1 Way Switch SW7-04-1 3Gang 2 Way Switch	SW7-05 4Gang 1 Way Switch SW7-05-1 4Gang 2 Way Switch
				
SW7-06 Door Bell Switch	SW7-07 2 Pin Socket	SW7-08 3 Pole Socket	SW7-09 Thailand 3 Pole Socket	SW7-10 2 MF Socket

				
SW7-11 1Gang 1 Way Switch +Thailand Socket SW7-11-1 1Gang 2 Way Switch +Thailand Socket	SW7-12 1Gang 1 Way Switch +3 Pole Socket SW7-12-1 1Gang 2 Way Switch +3 Pole Socket	SW7-13 1Gang 1 Way Switch +MF Socket SW7-13-1 1Gang 2 Way Switch +MF Socket	SW7-14 2 MF Socket	SW7-15 2*13A Socket
				
SW7-16 Double 2 Pin Socket	SW7-17 Double 3 Pole Socket	SW7-18 Double Thailand 3 Pole Socket	SW7-19 1Gang 1 Way Switch +Double 2 Pin Socket SW7-19-1 1Gang 2 Way Switch +Double 2 Pin Socket	SW7-20 1Gang 1 Way Switch +Double 3 Pole Socket SW7-20-1 1Gang 2 Way Switch +Double 3 Pole Socket
				
SW7-21 1Gang 1 Way Switch +2 Brazil Socket SW7-21-1 1Gang 2 Way Switch +2 Brazil Socket	SW7-22 Triple 2 Pin Socket	SW7-23 Triple 3 Pole Socket	SW7-24 6 Pole Socket + USB	SW7-25 16A Germany Socket
				
SW7-26 1Gang 1 Way Switch + 16A Germany Socket SW7-26-1 1Gang 2 Way Switch + 16A Germany Socket	SW7-27 Thailand 3 Pole+USB Socket	SW7-28 3 Pole+USB Socket	SW7-29 1Gang 1 Way Switch and Indicator light+2 Pin Socket SW7-29-1 1Gang 2 Way Switch and Indicator light+2 Pin Socket	SW7-30 20-25A
				
SW7-31 TV	SW7-32 TEL Socket SW7-33 Computer Socket	SW7-34 Satelite Socket	SW7-35 Dimmer Switch SW7-36 Speed Control Switch	SW7-37 Voice Control Switch SW7-38 Touch Switch

brushed panel.

SW8 SERIES



SW17 SERIES

SW17 SERIES

SW8 SERIES



SW8-01
1Gang 1 Way Switch
SW8-01-1
1Gang 2 Way Switch



SW8-02
1Gang 1 Way Switch
SW8-02-1
1Gang 2 Way Switch



SW8-03
2Gang 1 Way Switch
SW8-03-1
2Gang 2 Way Switch



SW8-04
3Gang 1 Way Switch
SW8-04-1
3Gang 2 Way Switch



SW8-05
4Gang 1 Way Switch
SW8-05-1
4Gang 2 Way Switch




SW8-06
Door Bell Switch



SW8-07
2 Pin Socket




SW8-08
3 Pole Socket



SW8-09
Thailand 3 Pole Socket



SW8-10
2 MF Socket




SW8-11
1Gang 1 Way Switch
+Thailand Socket




SW8-11-1
1Gang 2 Way Switch
+Thailand Socket



SW8-12
1Gang 1 Way Switch
+3 Pole Socket




SW8-12-1
1Gang 2 Way Switch
+3 Pole Socket




SW8-13
1Gang 1 Way Switch
+MF Socket



SW8-13-1
1Gang 2 Way Switch
+MF Socket



SW8-14
2 MF Socket



SW8-15
2*13A Socket



SW8-16
Double 2 Pin Socket



SW8-17
Double 3 Pole Socket



SW8-18
Double Thailand
3 Pole Socket



SW8-19
1Gang 1 Way Switch
+Double 2 Pin Socket




SW8-20
1Gang 1 Way Switch
+Double 3 Pole Socket



SW8-21
1Gang 1 Way Switch
+2 Brazil Socket



SW8-22
Triple 2 Pin Socket




SW8-23
Triple 3 Pole Socket



SW8-24
6 Pole Socket + USB



SW8-25
16A Germany Socket



SW8-21-1
1Gang 2 Way Switch
+2 Brazil Socket



SW8-26
1Gang 1 Way Switch
+ 16A Germany Socket
SW8-26-1
1Gang 2 Way Switch
+16A Germany Socket




SW8-27
Thailand 3 Pole+USB Socket




SW8-28
3 Pole+USB Socket



SW8-29
1Gang 1 Way Switch
and Indicator light+2 Pin Socket
SW8-29-1
1Gang 2 Way Switch
and Indicator light+2 Pin Socket



SW8-30
20-25A



SW8-31
TV



SW8-32
TEL Socket



SW8-34
Satellite Socket



SW8-35
Dimmer Switch



SW8-37
Voice Control Switch

SW8-33
Computer Socket

SW8-36
Speed Control Switch

SW8-38
Touch Switch

SW9 SERIES

acrylic
panel.



SW9-01
1Gang 1 Way Switch
SW9-01-1
1Gang 2 Way Switch



SW9-02
1Gang 1 Way Switch
SW9-02-1
1Gang 2 Way Switch



SW9-03
2Gang 1 Way Switch
SW9-03-1
2Gang 2 Way Switch



SW9-04
3Gang 1 Way Switch
SW9-04-1
3Gang 2 Way Switch



SW9-05
4Gang 1 Way Switch
SW9-05-1
4Gang 2 Way Switch



SW9-06
Door Bell Switch



SW9-07
2 Pin Socket



SW9-08
3 Pole Socket



SW9-09
Thailand 3 Pole Socket



SW9-10
2 MF Socket




SW9-11
1Gang 1 Way Switch
+Thailand Socket



SW9-11-1
1Gang 2 Way Switch
+Thailand Socket



SW9-12
1Gang 1 Way Switch
+3 Pole Socket



SW9-12-1
1Gang 2 Way Switch
+3 Pole Socket



SW9-13
1Gang 1 Way Switch
+MF Socket



SW9-13-1
1Gang 2 Way Switch
+MF Socket



SW9-14
2 MF Socket



SW9-15
2*13A Socket



SW9-16
Double 2 Pin Socket



SW9-17
Double 3 Pole Socket



SW9-18
Double Thailand
3 Pole Socket




SW9-19
1Gang 1 Way Switch
+Double 2 Pin Socket



SW9-20
1Gang 1 Way Switch
+Double 3 Pole Socket



SW9-21
1Gang 1 Way Switch
+2 Brazil Socket



SW9-21-1
1Gang 2 Way Switch
+2 Brazil Socket



SW9-22
Triple 2 Pin Socket



SW9-23
Triple 3 Pole Socket



SW9-24
6 Pole Socket + USB



SW9-25
16A Germany Socket



SW9-26
1Gang 1 Way Switch
+ 16A Germany Socket
SW9-26-1
1Gang 2 Way Switch
+ 16A Germany Socket



SW9-27
Thailand 3 Pole+USB Socket



SW9-28
3 Pole+USB Socket



SW9-29
1Gang 1 Way Switch
and Indicator light+2 Pin Socket
SW9-29-1
1Gang 2 Way Switch
and Indicator light+2 Pin Socket



SW9-30
20-25A



SW9-31
TV



SW9-32
TEL Socket

SW9-33
Computer Socket



SW9-34
Satellite Socket



SW9-35
Dimmer Switch

SW9-36
Speed Control Switch




SW9-37
Voice Control Switch

SW9-38
Touch Switch



SW10 (SERIES)
acrylic
panel.



- | | |
|--------------|---------------|
| White panel | Gold panel |
| Mood panel | Green panel |
| Gray panel | Magenta panel |
| Orange panel | Black panel |



SW10 SERIES

PC Material Panel

 Switch socket  life Electrical



SW10-01
1Gang 1 Way Switch
SW10-01-1
1Gang 2 Way Switch

SW10-02
2Gang 1 Way Switch
SW10-02-1
2Gang 2 Way Switch

SW10-03
1Gang 1 Way Switch
+ 2 Pin Socket
SW10-03-1
1Gang 2 Way Switch
+ 2 Pin Socket

SW10-04
1Gang 1 Way Switch
+ 3 Pole Socket
SW10-04-1
1Gang 2 Way Switch
+ 3 Pole Socket

SW10-05
1Gang 1 Way Switch
+ Italian Socket
SW10-05-1
1Gang 2 Way Switch
+ Italian Socket



SW10-06
Double 2 Pin Socket

SW10-07
1Gang 1 Way Switch
+ Double 3 Pole Socket
SW10-07-1
1Gang 2 Way Switch
+ Double 3 Pole Socket

SW10-08
1Gang 1 Way Switch
+ 2 Brazil Socket
SW10-08-1
1Gang 2 Way Switch
+ 2 Brazil Socket

SW10-09
Triple 2 Pin Socket

SW10-10
Triple 3 Pole Socket



SW10-11
6 Pole Socket + USB

SW10-12
16A Germany Socket

SW10-13
1Gang 1 Way Switch
+ 16A Germany Socket
SW10-13-1
1Gang 2 Way Switch
+ 16A Germany Socket

SW10-14
2 MF Socket

SW10-15
2*13A Socket



SW10-16
TV

SW10-17
TEL Socket
SW10-18
Computer Socket

SW10-19
Satellite Socket

SW10-20
1Gang 1 Way Switch
and Indicator light+2 Pin Socket
SW10-20-1
1Gang 2 Way Switch
and Indicator light+2 Pin Socket

SW10-21
20-25A



SW10-22
1Gang 1 Way Switch
SW10-22-1
1Gang 2 Way Switch

SW10-23
1Gang 1 Way Switch
SW10-23-1
1Gang 2 Way Switch

SW10-24
2Gang 1 Way Switch
SW10-24-1
2Gang 2 Way Switch

SW10-25
3Gang 1 Way Switch
SW10-25-1
3Gang 2 Way Switch

SW10-26
4Gang 1 Way Switch
SW10-26-1
4Gang 2 Way Switch



SW10-27
Door Bell Switch

SW10-28
2 Pin Socket

SW10-29
3 Pole Socket

SW10-30
Thailand 3 Pole Socket

SW10-31
MF Socket



SW10-32
2 MF Socket

SW10-33
1Gang 1 Way Switch
+ Thailand Socket
SW10-33-1
1Gang 2 Way Switch
+ Thailand Socket

SW10-34
1Gang 1 Way Switch
+ 3 Pole Socket
SW10-34-1
1Gang 2 Way Switch
+ 3 Pole Socket

SW10-35
1Gang 1 Way Switch
+ MF Socket
SW10-35-1
1Gang 2 Way Switch
+ MF Socket

SW10-36
Double 2 Pin Socket



SW10-37
Double 3 Pole Socket

SW10-38
Double Thailand
3 Pole Socket

SW10-39
Thailand 3 Pole+USB Socket

SW10-40
MF+USB Socket

SW10-41
3 Pole+USB Socket



SW10-42
TV

SW10-43
TEL Socket
SW10-44
Computer Socket

SW10-45
Satellite Socket

SW10-46
Dimmer Switch
SW10-47
Speed Control Switch

SW10-48
Voice Control Switch
SW10-49
Touch Switch

SW11 SERIES

PC Material Panel

SWITCH SOCKET



SW11-22
1Gang 1 Way Switch
SW11-22-1
1Gang 2 Way Switch



SW11-23
1Gang 1 Way Switch
SW11-23-1
1Gang 2 Way Switch



SW11-24
2Gang 1 Way Switch
SW11-24-1
2Gang 2 Way Switch



SW11-25
3Gang 1 Way Switch
SW11-25-1
3Gang 2 Way Switch




SW11-26
4Gang 1 Way Switch
SW11-26-1
4Gang 2 Way Switch



SW11-01
1Gang 1 Way Switch
SW11-01-1
1Gang 2 Way Switch



SW11-02
2Gang 1 Way Switch
SW11-02-1
2Gang 2 Way Switch



SW11-03
1Gang 1 Way Switch
+ 2 Pin Socket
SW11-03-1
1Gang 2 Way Switch
+ 2 Pin Socket



SW11-04
1Gang 1 Way Switch
+ 3 Pole Socket
SW11-04-1
1Gang 2 Way Switch
+ 3 Pole Socket



SW11-05
1Gang 1 Way Switch
+ Italian Socket
SW11-05-1
1Gang 2 Way Switch
+ Italian Socket



SW11-27
Door Bell Switch



SW11-28
2 Pin Socket



SW11-29
3 Pole Socket




SW11-30
Thailand 3 Pole Socket



SW11-31
MF Socket




SW11-06
Double 2 Pin Socket




SW11-07
1Gang 1 Way Switch
+ Double 3 Pole Socket
SW11-07-1
1Gang 2 Way Switch
+ Double 3 Pole Socket



SW11-08
1Gang 1 Way Switch
+ 2 Brazil Socket
SW11-08-1
1Gang 2 Way Switch
+ 2 Brazil Socket



SW11-09
Triple 2 Pin Socket



SW11-10
Triple 3 Pole Socket



SW11-32
2 MF Socket



SW11-33
1Gang 1 Way Switch
+ Thailand Socket
SW11-33-1
1Gang 2 Way Switch
+ Thailand Socket




SW11-34
1Gang 1 Way Switch
+ 3 Pole Socket
SW11-34-1
1Gang 2 Way Switch
+ 3 Pole Socket




SW11-35
1Gang 1 Way Switch
+ MF Socket
SW11-35-1
1Gang 2 Way Switch
+ MF Socket



SW11-36
Double 2 Pin Socket




SW11-11
6 Pole Socket + USB




SW11-12
16A Germany Socket



SW11-13
1Gang 1 Way Switch
+ 16A Germany Socket
SW11-13-1
1Gang 2 Way Switch
+ 16A Germany Socket



SW11-14
2 MF Socket



SW11-15
2*13A Socket




SW11-37
Double 3 Pole Socket




SW11-38
Double Thailand
3 Pole Socket




SW11-39
Thailand 3 Pole+USB Socket



SW11-40
MF+USB Socket



SW11-41
3 Pole+USB Socket



SW11-16
TV



SW11-17
TEL Socket



SW11-19
Satellite Socket



SW11-20
1Gang 1 Way Switch
and Indicator light+2 Pin Socket
SW11-20-1
1Gang 2 Way Switch
and Indicator light+2 Pin Socket



SW11-21
20-25A



SW11-42
TV



SW11-43
TEL Socket



SW11-45
Satellite Socket



SW11-46
Dimmer Switch



SW11-48
Voice Control Switch


SW11-18
Computer Socket

SW11-44
Computer Socket

SW11-47
Speed Control Switch

SW11-49
Touch Switch

SW11 SERIES



brushed
panel.



SW18 SERIES

art switch
Fashion

provide the global home with great idea and create a beautiful home,
its electrical accessories not only excellent in function,
but also add unlimited fun and personalized features for your living space,
we brought together singularity with inspiration, will create a unique household environment for you.

SW18 SERIES

PC Material Panel

SWITCH SOCKET



SW18-22
1Gang 1 Way Switch
SW18-22-1
1Gang 2 Way Switch




SW18-23
1Gang 1 Way Switch
SW18-23-1
1Gang 2 Way Switch



SW18-24
2Gang 1 Way Switch
SW18-24-1
2Gang 2 Way Switch




SW18-25
3Gang 1 Way Switch
SW18-25-1
3Gang 2 Way Switch



SW18-26
4Gang 1 Way Switch
SW18-26-1
4Gang 2 Way Switch




SW18-01
1Gang 1 Way Switch
SW18-01-1
1Gang 2 Way Switch




SW18-02
2Gang 1 Way Switch
SW18-02-1
2Gang 2 Way Switch



SW18-03
1Gang 1 Way Switch
+ 2 Pin Socket
SW18-03-1
1Gang 2 Way Switch
+ 2 Pin Socket



SW18-04
1Gang 1 Way Switch
+ 3 Pole Socket
SW18-04-1
1Gang 2 Way Switch
+ 3 Pole Socket



SW18-05
1Gang 1 Way Switch
+ Italian Socket
SW18-05-1
1Gang 2 Way Switch
+ Italian Socket



SW18-27
Door Bell Switch



SW18-28
2 Pin Socket



SW18-29
3 Pole Socket




SW18-30
Thailand 3 Pole Socket



SW18-31
MF Socket



SW18-06
Double 2 Pin Socket




SW18-07
1Gang 1 Way Switch
+ Double 3 Pole Socket
SW18-07-1
1Gang 2 Way Switch
+ Double 3 Pole Socket



SW18-08
1Gang 1 Way Switch
+ 2 Brazil Socket
SW18-08-1
1Gang 2 Way Switch
+ 2 Brazil Socket



SW18-09
Triple 2 Pin Socket



SW18-10
Triple 3 Pole Socket



SW18-32
2 MF Socket



SW18-33
1Gang 1 Way Switch
+ Thailand Socket
SW18-33-1
1Gang 2 Way Switch
+ Thailand Socket




SW18-34
1Gang 1 Way Switch
+ 3 Pole Socket
SW18-34-1
1Gang 2 Way Switch
+ 3 Pole Socket




SW18-35
1Gang 1 Way Switch
+ MF Socket
SW18-35-1
1Gang 2 Way Switch
+ MF Socket



SW18-36
Double 2 Pin Socket



SW18-11
6 Pole Socket + USB




SW18-12
16A Germany Socket



SW18-13
1Gang 1 Way Switch
+ 16A Germany Socket
SW18-13-1
1Gang 2 Way Switch
+ 16A Germany Socket




SW18-14
2 MF Socket




SW18-15
2*13A Socket




SW18-37
Double 3 Pole Socket



SW18-38
Double Thailand
3 Pole Socket



SW18-39
Thailand 3 Pole+USB Socket



SW18-40
MF+USB Socket



SW18-41
3 Pole+USB Socket



SW18-16
TV




SW18-17
TEL Socket




SW18-19
Satellite Socket




SW18-20
1Gang 1 Way Switch
and Indicator light+2 Pin Socket
SW18-20-1
1Gang 2 Way Switch
and Indicator light+2 Pin Socket



SW18-21
20-25A



SW18-42
TV



SW18-43
TEL Socket



SW18-45
Satellite Socket



SW18-46
Dimmer Switch



SW18-48
Voice Control Switch

SW18-18
Computer Socket

SW18-44
Computer Socket

SW18-47
Speed Control Switch

SW18-49
Touch Switch



SW15 SERIES

provide the global home with great idea and create a beautiful home, its electrical accessories not only excellent in function, but also add unlimited fun and personalized features for your living space, we brought together singularity with inspiration, will create a unique household environment for you.



SW1-01
1Gang 1 Way Switch
SW1-01-1
1Gang 2 Way Switch



SW1-02
1Gang 1 Way Switch
SW1-02-1
1Gang 2 Way Switch



SW1-03
2Gang 1 Way Switch
SW1-03-1
2Gang 2 Way Switch



SW1-04
3Gang 1 Way Switch
SW1-04-1
3Gang 2 Way Switch



SW1-05
4Gang 1 Way Switch
SW1-05-1
4Gang 2 Way Switch



SW1-06
Door Bell Switch



SW1-07
15A/125V



SW1-08
3 Pole Socket



SW1-09
Thailand 3 Pole Socket



SW1-10
2 MF Socket




SW1-11
1Gang 1 Way Switch
+Thailand Socket



SW1-11-1
1Gang 2 Way Switch
+Thailand Socket



SW1-12
1Gang 1 Way Switch
+3 Pole Socket



SW1-12-1
1Gang 2 Way Switch
+3 Pole Socket



SW1-13
1Gang 1 Way Switch
+MF Socket



SW1-13-1
1Gang 2 Way Switch
+MF Socket



SW1-14
2 MF Socket



SW1-15
2*13A Socket



SW1-16
Double 2 Pin Socket



SW1-17
Double 3 Pole Socket



SW1-18
Double Thailand
3 Pole Socket



SW1-19
1Gang 1 Way Switch
+Double 2 Pin Socket



SW1-20
1Gang 1 Way Switch
+Double 3 Pole Socket




SW1-21
1Gang 1 Way Switch
+2 Brazil Socket




SW1-22
Triple 2 Pin Socket




SW1-23
Triple 3 Pole Socket



SW1-24
6 Pole Socket
+ USB



SW1-25
16A Germany Socket



SW1-21-1
1Gang 2 Way Switch
+2 Brazil Socket



SW1-26
1Gang 1 Way Switch
+ 16A Germany Socket
SW1-26-1
1Gang 2 Way Switch
+ 16A Germany Socket



SW1-27
Thailand 3 Pole+USB Socket



SW1-28
3 Pole+USB Socket



SW1-29
1Gang 1 Way Switch
and Indicator light+2 Pin Socket
SW1-29-1
1Gang 2 Way Switch
and Indicator light+2 Pin Socket



SW1-30
20-25A



SW1-31
TV



SW1-32
TEL Socket



SW1-33
Computer Socket



SW1-34
Satellite Socket



SW1-35
Dimmer Switch

SW1-36
Speed Control Switch

SW1-37
Voice Control Switch

SW1-38
Touch Switch

